
B12

Pressure switches up to 28 bar with adjustable differential

Pressure switches for control and regulation of all fluids and non-explosive gases. Suitable for compression plants, boilers, tanks, autoclaves, ventilation plants, lubrication plants.






	Range	Differential bar	Sensitive element max. pressure bar	Connection G/14	Protection degree	Availability
B12CN	-0,2 ÷ 8	0,6 ÷ 3	9	flange	IP40	in stock
DIZCIN	-U,Z - O	0,0 ÷ 3	7	rtange	1740	III Stock
B12DN	5 ÷ 16	1 ÷ 3,5	18	flange	IP40	in stock
B12EN	8 ÷ 28	2 ÷ 6	32	flange	IP40	in stock
B12CRN	-0,2 ÷ 8	0,6 ÷ 3	9	SAE	IP40	in stock
B12ERN	-8 ÷ 28	2 ÷ 6	32	SAE	IP40	in stock
B12CN4	-0,2 ÷ 8	0,6 ÷ 3	9	threaded	IP40	on request
B12DN4	5 ÷ 16	1 ÷ 3,5	18	threaded	IP40	on request
B12EN4	8 ÷ 28	2 ÷ 6	32	threaded	IP40	on request
WITH BLOCK	KING AND MANU	AL RESET				
B12CMN	1 ÷ 8	0,6 ÷ 3	9	flange	IP40	on request
B12DMN	5 ÷ 16	1 ÷ 3,5	18	flange	IP40	on request
B12EMN	8 ÷ 28	2 ÷ 6	32	flange	IP40	on request

WATERPROOF CASING EXECUTION





B12CNY	-0,2 ÷ 8	0,6 ÷ 3	9	flange	IP65	in stock
B12DNY	5 ÷ 16	1 ÷ 3,5	18	flange	IP65	in stock
B12ENY	8 ÷ 28	2 ÷ 6	32	flange	IP65	in stock
B12CRNY	-0,2 ÷ 8	0,6 ÷ 3	9	flange	IP65	in stock
B12ERNY	8 ÷ 28	2 ÷ 6	32	flange	IP65	in stock

¹ Bar = 100Kpa *The differential must be deducted from the range value.

ELECTRICAL FEATURES


Snap action SPDT microswitch, contacts in AgCdO.



Nominal insulation tension Ui 415V~ Continuous duty nominal current Ith 16A

Operating nominal current le 220V- 380/415V~

Resistive load AC-1 - 16A
Inductive load AC-3 - 6A
Continuous current DC-13 0,2A -



HOMOLOGATION AND STANDARDS

Complies with EN 60947-4-1 standards.


INSTALLATION

Direct installation on the pipe.

Pressure element connection G 1/4.

In case of fluid temperatures higher than the maximum allowed, connect the pressure switch to the pipe by inserting a metallic spiral between the pressure switch and the pipe to facilitate heat dispersion.

Possibility of mounting on metallic clamp, exept for the waterproof casing versions.



OPERATION

When pressure increases: 1-2 opens, 1-4 closes.

In the pressure switch with blocking and manual reset at maximum pressure, the reset takes place when the pressure is below the value set on differential.

FEATURES

Sensitive element with stainless steel membrane, laser welded.

Metallic frame.

Cover in shockproof thermoplastic material.

Output connections with PVC cable gland.

Fixed differential.

Flange connection G 1/4 (17 mm key).

Maximum temperature of the controlled fluid: 120 °C. Pressure switch body admissible temperature: $-35 \div 60$ °C.

Storage and transport temperature: -35 ÷ 60°C.

Unit weight: 0,43 Kg B12AN. Unit weight: 0,44 Kg B12BN.

ACCESSORIES



303298LA

G1/2 cable gland in V0 self-extinguishing, shockproof thermoplastic material for output connections.



2593367

Protection casing IP44.